

## eco-clear cleaning instructions



1. Remove any debris from the urinal such as chewing gum and other foreign matter



2. Spray the surface of the urinal bowl and the tiles around it with eco-clear cleaning solution and wipe clean

Note: Do not use any bleach, disinfectants, acids or chemicals



Sleeve

Collar

Extension Tube

3. Once a month, remove the eco-clear sleeve before spraying with the cleaning solution

Note: When removing the sleeve ensure that you pull it directly upwards. Do not remove it at an angle. Please ensure the extension tube remains in place. If the collar comes out of the waste outlet, you should replace it before re-inserting the sleeve. Do not push any debris such as chewing gum through the waste outlet



Yes

4. Inspect the cap to ensure there is a significant amount of green block present?

Note: If yes, please go to point 6. If no, please go to point 5



No

5. If there is only a small amount of, or no green block remaining, please call Enviro-Fresh on 0845 603 6367 as the sleeve needs to be replaced



6. Once you have thoroughly cleaned the urinal bowl, ensure that the collar and extension tube are in place and replace the sleeve by inserting it into the waste outlet and pressing down firmly